

Chair Sizing & Caster Chart

Seat depth: accommodates different leg lengths.
 The seat depth can be manually adjusted with one side handle.

Seat height: accommodates different body heights.
 The seat height can be manually adjusted up and down with one handle on the side, and the lumbar support can be raised or lowered by setting one knob at the back.

CorrectSit®

Cylinder size M if body height < 6 ft
 Cylinder size L if body height > 6 ft

ErgoSolex®

Cylinder size M if body height < 5 ft 8"
 Cylinder size L if body height > 5 ft 8"
 Cylinder size X if body height > 6 ft 4", or if work surface is raised

ComfortMove®

Cylinder size S if body height < 5 ft 4"
 Cylinder size M if body height < 6 ft 4"
 Cylinder size L if body height > 6 ft"

ErgoDynamic®

Cylinder size M if body height < 6 ft
 Cylinder size L if body height > 6 ft

Tilting mechanism ErgoDynamic:

350N if body weight is < 110 lbs
 450N if body weight is between 110 - 160 lbs
 550N if body weight is between 160 - 240 lbs
 650N if body weight is > 240 lbs (maximum 275 lbs)
 Seat Extra-wide seat available upon request. Is included with 650N models.

Caster Types

1. Hard floor casters (black ABS plastic, 50mm diameter)
2. Carpet casters (silver colored ABS plastic with black rubber, 60mm diameter)
3. Sit-Lock casters (Black/Grey Rubber, 50mm diameter)
4. Rise-Lock casters (Black/Grey Rubber, 50mm diameter)
5. Sliders (Black Plastic, 50mm - 60mm diameter)

