

# Dismantling ErgoDynamic®

- 1: Place the ErgoDynamic® upside down. Place the gas lift in the highest position. Lift the ErgoDynamic® by the base with your left hand so that the seat would reach the height of a table. Now hit the mechanism a couple times with a heavy hammer (a fist) till the upper part comes loose from the gas lift. To avoid the damage place a towel or something soft over the point which you are about to hit. (See Pic. 1).
- 2: Keep the cross feet upside down and let it rest on your hand. Hit the edge of a gas lift with the hammer. It will come loose. (See Pic. 2).



**BQ Ergonomics LLC**

**7300 S Tucson Way  
Centennial, CO 80112**

**phone:**

**Fax:**

**email:**

**web:**

**303.991.8802**

**303.693.2257**

**info@BQErgonomics.com**

**www.BQErgonomics.com**