

Instructions for use ComfortMove®

Right lever (no.1): **height adjustment.**

Adjust the height of the ComfortMove so that the tights remain horizontal or if better pointing down a little forming an angle of 90 up to 100° in the hip.

Lever on the back right side (no.2): **adjustment of the seat depth and inclination of the backrest.**

Push up the lever to liberate the mechanism. Push firstly with your back the backrest as far as your thighs stay 2 cm from the seat. You can now sit correctly. Deepest point of the lumbar area is on the high of the trousers belt. When that is reached you push the lever down to fix the backrest.

Pull up of the back (nr.3): **adjustment of the height of the backrest.**

To fix the height of the backrest, pull up the backrest till you place the backrest on the correct high. To place the backrest lower, you must pull up completely the backrest and then the backrest automatically slides down. Place the backrest so that its height gives support to your back. The average height for the backrest depends on the size of the trousers belt.



BQ Ergonomics LLC

**7300 S Tucson Way
Centennial, CO 80112**

phone:

Fax:

email:

web:

303.991.8802

303.693.2257

info@BQErgonomics.com

www.BQErgonomics.com